

Screen Cluster MCU Upgrade Steps:

1. Format your USB Drive into FAT32 format and make it empty (no other files inside);
Attention: It's better to use one USB Disk with memory capacity of 16GB or smaller.
2. Open MCU file and copy xs_can_app3.bin into above USB disk (just copy it directly into above empty USB disk with FAT32 format);
3. Plug the USB Disk to USB socket at the right side of screen cluster;
4. Start your car and screen cluster turns on, then enter vehicle setting → General → Version Information → MCU upgrade → Upgrade will be complete around 35 seconds and the screen will reboot → Unplug USB Disk;

Note: The screen cluster can't be off during upgrading;

After machine reboot, enter version information to check again, the last line (Original version of MCU0 version: mdl3-Ab1.09-1C20) will be changed.

